


AKCESORIA KURTYN SG4 BODY SG-F1-G1-ARMS



OPIS PRODUKTU

ORDERING SUMMARY TABLE FOR MUTING ACCESSORIES

SAFETY CURTAIN	MUTING	TYPE	SG-F1- ARM V1	SG-F1- ARM V2	SG-F1- ARM V3	SG-F1- ARM V4	SG-F1- ARM V5	SG-F1- ARM V6	SG-F1- ARM V7	SG-F1- ARM V8	SG-F1- ARM V9	SG-F1- ARM V10	SG-F1- ARM V11	SG-F1- ARM V12
SG-F1- ARM V1	L	ARM	1	1	2				1					
	R	ARM	2	2	2				1					
	L	F10			2				2			1		
	T	F10			2				2			1	1	
SG-F1- ARM V2	L	ARM		1	1	2			1					
	R	ARM		2	2	2			1					
	L	F10							2			1		
	T	F10							2			1	1	
SG-F1- ARM V3	L	ARM	1											
	R	ARM		1										
	L	F10			2				2			1		
	T	F10			2				2			1	1	
SG-F1- ARM V4	L	ARM												
	R	ARM												
	L	F10												
	T	F10												

NOTES:
 ARM - Actual Picture of the curtain arm
 F10 - End of the curtain arm

