





Meaning of contamination error numbers

Errors related to optical window contamination are summarized in the following table:

Error number	Angle of the contamination	Image
B1 or B9	0~30°	
B2 or BA	30~65°	
B3 or BB	65~100°	
B4 or BC	100~135°	
B5 or BD	135~170°	

B6 or BE	170~205°	
B7 or BF	205~240°	
B8 or C0	240~270°	
C1	All the field of view	